

US EPA ARCHIVE DOCUMENT

New Monitoring and Assessment Approaches for HABs in California

Meredith D.A. Howard

Southern California Coastal Water Research Project
Costa Mesa, California



Collaborators

University of California, Santa Cruz
Raphael Kudela
Kendra Hayashi

University of Southern California
David Caron
Avery Tatters
Jayme Smith
Alyssa Gellene

San Diego Regional Waterboard
Carey Nagoda
Betty Fetscher
Chad Loflen

Pasadena City College
Erica Seubert

Santa Ana Regional Waterboard
Heather Boyd

Los Angeles Regional Waterboard
Michael Lyons

German Federal Environmental Agency
Lilian Busse

Orange County Sanitation District
George Robertson
Michael Mengel
Laura Terriquez


SCCWRP
Martha Sutula
Eric Stein
Jeff Brown

Historic Cyanotoxin Hotspots in California



Recurrent Blue Green Algae Blooms In California Waterbodies

OEHHA Fact Sheet




Record Breaking Years 2014 – 2015



- First time several lakes closed due to cyanotoxins
- Extremely high microcystin concentrations recorded
- Several dog deaths attributed to cyanotoxins
- Multiple toxins detected simultaneously
- Fish kills caused by *Pyrmnesium parvum*

Far-Reaching Effects of Freshwater Toxins to Marine Waters




*Mortality of sea otters due to
microcystin intoxication*



Miller et al., 2010

Benthic Algae from Wadeable Streams a Potential Source of Toxin Loading to Downstream Waterbodies



Fetscher et al. 2015 Harmful Algae


Microcystins detected at 33% of sites in California

Microcystins detected in 30-40% of sites in southeastern US stream study (water samples, not benthic algae) (Loftin et al., 2016)

Monitoring Tool: Solid Phase Adsorption Toxin Tracking SPATT

Passive sampler that is time-integrative

- Applicable in all waterbody types (marine, brackish, freshwater)
- Detects both freshwater and marine toxins
- Amenable to multiple toxin detection methods
- Low cost, simple and easy to deploy/recover
- *Disadvantage:* SPATT will not provide a concentration of toxin that is applicable to health advisory thresholds
 - ng/g units



Solid Phase Adsorption Toxin Tracking (SPATT)

- Has been used in many areas of the world for the monitoring of dissolved algal toxins
 - Anatoxins (Wood et al 2011)
 - Azaspiracids (Fu et al 2009)
 - Dinophysistoxins (Fu et al 2008, 2009, Pizarro et al 2013)
 - Domoic acid (Lane et al 2010)
 - Microcystins (Kudela 2011)
 - Okadaic acid (MacKenzie et al 2004, Fu et al 2008, 2009)
 - Pectenotoxins (MacKenzie et al 2004, Fu et al 2009)
 - Saxitoxin (Lane et al 2010)
 - Spirolide toxins (Fu et al 2009)
 - Yessotoxins (MacKenzie et al 2004, Fu et al 2009)



Why Use SPATT?

Persistence of Cyanotoxins


Do microcystins persistently flow into Monterey Bay from surrounding watersheds?

Answer: YES! Microcystins were persistently present over several years.

- Toxin peaks were in the spring and autumn seasons

2010-2011 Monthly deployments

2011-2013 Weekly deployments




- Microcystins detected
- Microcystins not detected

Why Use SPATT?


Determine Toxin *Prevalence*

- Condition assessments and screening studies
- Waterbodies with little to no HAB data
- Determine the prevalence of toxin across a region
 - Depressional wetlands assessment (probabilistic design)
 - Lakes, estuaries and reservoirs (targeted design)




Microcystin Prevalence Underestimated From Grab Samples By ~50%

Grab Sample



SPATT Sample



% of Toxic Sites: Depressional Wetlands

Grab Samples	29%
SPATT Samples	83%



Microcystins Detected at Every Site Sampled

San Diego County: Lakes, Reservoirs, Estuaries and Coastal Lagoons

Grab Sample Results


SPATT Sample Results:

All sites toxic





Why Use SPATT?

Deploy In Areas with Limited or No Sampling



1 meter depth

7 meter depth



Pier:
DA below detection

Domoic Acid
Saxitoxin
Okadaic Acid

Seubert et al., in prep

Many Ways To Deploy SPATT in Aquatic Environments


- Piers and floating docks
- Instruments deployed in the water
- PVC Tube in sediment
- Buoy and moorings
- Autonomous Underwater Vehicles
- Ship flow through system



SPATT Deployment: Pier, Dock, Instruments, PVC Tube




SPATT Deployment: Buoy and Mooring




SPATT Deployment: AUVs

Liquid Robotics G5 surface wave glider



Berdalet et al., 2014

SPATT and Grab samples showed similar results: a persistent increase in DA




SPATT Deployment: AUVs



Teledyne Webb Slocum Gliders



SPATT detected domoic acid, saxitoxin;
no okadaic acid detected



Ship Flow-Through System



Conclusions and Future Directions

- SPATT Advantages:
 - Low cost, easy to deploy tool
 - Applicable to marine, brackish and freshwater environments
 - Measures marine and freshwater toxins
 - Can be deployed in many different ways and in areas where there is limited sampling
 - More robust indicator of toxin prevalence compared to grab samples ('snapshots')
- Disadvantages:
 - Cannot be directly compared to health advisory thresholds
- MERHAB: Improve tools for monitoring multiple HAB toxins at the land-sea interface in CA
 - Develop SPATT for additional toxins and implement an integrated multi-toxin HAB strategy

Thank You!

NOAA (MERHAB NA05NO54781228 and ECOHAB NA11NOS4780053)

Orange County Sanitation District

