US ERA ARCHIVE DOCUMENT

5/19/1957

DATA EVALUATION RECORD ACUTE LC₅₀ TEST WITH AN ESTUARINE/MARINE SHRIMP § 72-3(C)

1. CHEMICAL: Zinc Omadine PC Code No.: 001258

2. TEST MATERIAL: Zinc bis-1-oxide-2(1H)-pryidenethionate, off-white powder,

CAS No.13463-41-7 Purity: 97.8%

3. CITATION

Authors: R. L. Boeri, J. P. Magazu, and T. J. Ward

Title: Acute toxicity of Zinc Omadine to the Mysid,

Mysidopsis bahia.

Study Completion Date: 11 July 1993

Laboratory: T. R. Wilbury Laboratories, Inc., Marblehead, MA

Sponsor: Olin Corp., New Haven, CT

Laboratory Report ID: 23-OL

MRID No.: 438646-07 DP Barcode: D228348

4. REVIEWED BY: Regina Hirsch, Wildlife Biologist, EEB, EFED

Date: 1/6/97

5. APPROVED BY: Les Touart, Head of Section (1), EEB, EFED

Signature:

16 h7 -

Date: 5/19/97

6. STUDY PARAMETERS

Scientific Name of Test Organism: Mysidopsis bahia

Age or Size of Test Organism: 1.5 mg

Definitive Test Duration: 96 hours

Study Method: Flow-through

Type of Concentrations: Mean measured

7. CONCLUSIONS:

Results Synopsis

 LC_{50} : 4.7 $\mu g/L$ ai

95% C.I.: 4.04 - 5.53 μg/L ai

NOEL: 1.6 μg/L ai

8. ADEQUACY OF THE STUDY

A. Classification: Core.

B. Rationale: N/A

C. Repairability: N/A

9. BACKGROUND

10. GUIDELINE DEVIATIONS

1. Dilution water contained dechlorinated tap water.

2. Total organic carbon was not reported.

11. **SUBMISSION PURPOSE**: Registration

12. MATERIALS AND METHODS

A. Test Organisms

| Guideline Criteria | Reported Information Assets |
|---|---------------------------------------|
| Species Preferred species are Mysidopsis bahia, Penaeus setiferus, P. duorarun, P. aztecus and Palaemonetes sp. | Mysidopsis bahia |
| Age Juvenile, mysids should be ≤ 24 hours old | <24 hours old |
| <u>Supplier</u> | Aquatic Indicators, St. Augustine, FL |
| All shrimp are from same source? | Yes |
| All shrimp are from the same year class? | Yes |

B. Source/Acclimation

| Guideline Criteria | Reported Information |
|---|--|
| Acclimation Period minimum 10 days | 14 days |
| Wild caught organisms were quarantined for 7 days? | N/A |
| Were there signs of disease or injury? | No |
| If treated for disease, was there no sign of the disease remaining during the 48 hours prior to testing? | N/A |
| Feeding No feeding during the study and no feeding for 24 hour before the beginning of the test if organisms are over 0.5 g each. | Mysids were fed live Artmia salina daily during acclimation and testing. |
| Pretest Mortality <3% mortality 48 hours prior to testing | <3% mortality prior to testing. |

C. Test System

| Guideline Criteria | Reported Information |
|--|---|
| Source of dilution water Soft reconstituted water or water from a natural source, not dechlorinated tap water | dilution as natural filtered seawater adjusted with dechlorinated tapwater to the correct salinity. |
| Does water support test animals without observable signs of stress? | Yes |
| Salinity 30-34 for marine (stenohaline) shrimp and 10-17 for estuarine (euryhaline) shrimp, weekly range < 6 | 11 to 19 ppt |

| Guideline Criteria | Reported Information: |
|--|---|
| <u>Water Temperature</u> Approx. 22 <u>+</u> 1 °C | 21.3 to 22.9°C |
| pH 8.0-8.3 for marine (stenohaline) shrimp, 7.7-8.0 for estuarine (euryhaline) shrimp, monthly range < 0.8 | 7.1 to 8.0 |
| Dissolved Oxygen Static: ≥ 60% during 1 st 48 hrs and ≥ 40% during 2 nd 48 hrs, Flow-through: ≥ 60% | 7.9 mg/L at 24 hour |
| Total Organic Carbon | Not reported |
| Test Aquaria 1. Material: Glass or stainless steel 2. Size: 19.6 L is acceptable for organisms ≥ 0.5 g (e.g. pink shrimp, white shrimp, and brown shrimp), 3.9 L is acceptable for smaller organisms (e.g. mysids and grass shrimp). 3. Fill volume: 15 L is acceptable for organisms ≥ 0.5 g, 2-3 L is acceptable for smaller organisms. | glass 20 L 15 L |
| Type of Dilution System Must provide reproducible supply of toxicant | Intermittent flow proportional diluter. The diluter was constructed at T. R. Wilbury Laboratories, allowed test media to contact only glass, stainless steel, or Teflon surfaces. |
| Flow Rate Consistent flow rate of 5-10 vol/24 hours, meter systems calibrated before study and checked twice daily during test period | 5.3 vol/24 hours |

| Guideline Criteria | Reported Mornation |
|--|---------------------------|
| Biomass Loading Rate Static: ≤ 0.8 g/L at ≤ 17°C, ≤ 0.5 g/L at > 17°C; flow-through: ≤ 1 g/L/day | 0.001 g/L (0.002 g/L/day) |
| Photoperiod 16 hours light, 8 hours dark | 16 h light, 8 h dark. |
| Solvents Not to exceed 0.5 ml/L for static tests or 0.1 ml/L for flow-through tests | None |

D. Test Design

| Guideline Criteria | Reported Information | | |
|--|--|--|--|
| Range Finding Test If LC ₅₀ > 100 mg/L with 30 shrimp, then no definitive test is required. | A screening test was not performed and historic data were used to determine the range of concnetrations for the definitive test. | | |
| Nominal Concentrations of Definitive Test Control & 5 treatment levels; a geometric series in which each concentration is at least 60% of the next higher one. | Control, 2.4, 4.0, 6.4, 9.6, 16 μg ai/L. | | |
| Number of Test Organisms Minimum 20/level, may be divided among containers | 20/Level (2 replicates with 10 organisms per replicate) | | |
| Test organisms randomly or impartially assigned to test vessels? | Yes | | |
| Biological observations made every 24 hours? | Yes | | |

| Guideline Criteria | Reported Information |
|---|--|
| Water Parameter Measurements 1. Temperature Measured constantly or, if water baths are used, every 6 hrs, may not vary > 1°C 2. DO and pH Measured at beginning of test and ever 48 h in the high, medium, and low doses and in the control | Temperature in one test vessel was recorded continuously during the test. DO, pH, and temperature were measured and recorded daily in each test chamber that contained live shrimp. |
| Chemical Analysis needed if solutions were aerated, if chemical was volatile, insoluble, or known to absorb, if precipitate formed, if containers were not steel or glass, or if flow-through system was used | Analytical determineation of test material concnetration from the test was performed on pooled samples collected midway between the top, bottom, and sides of the 2 replicates of each concentration at the beginning and end of the test. |

13. REPORTED RESULTS

A. General Results

| Guideline Criteria | Reported Information | | | |
|---|----------------------|--|--|--|
| Quality assurance and GLP compliance statements were included in the report? | Yes | | | |
| Recovery of Chemical | 67-106 % of Nominal | | | |
| Control Mortality Not more than 10% of control organisms may die or show abnormal behavior. | 0.05% | | | |
| Raw data included? | No | | | |
| Signs of toxicity (if any) were described? | Yes | | | |

Mortality

| Concentration (ppm): | | #Number | Cumulative Number Dead | | | |
|----------------------|------------------|--------------|------------------------|---------|-------|----|
| Nominal | Mean Measured | of Shrimp | . 24 | Hour of | Study | 96 |
| Control | 0.0 | 20 | 0 | 0 | 1 | 1 |
| 2.4 | 1.6 | 20 | 0 | 0 | 1 | 1 |
| 4.0 | 3.2 | 20 | 1 | 1 | 4 | 8 |
| 6.4 | 5.9 | 20 | 0 | 0 | 5 | 8 |
| 9.6 | 9.4 | 20 | 3 | 3 | 20 | 20 |
| 16.0 | 17.0 | 20 | 12 | 20 | 20 | 20 |

Other Significant Results:

No sublethal effects were observed.

B. Statistical Results

Method: Binomial/nonlinear interpolation

96-hr LC_{50} : 6.3 $\mu g/L$ ai

95% C.I.: 1.6 to 9.4 μg/L ai

Probit Slope: Could not be calculated NOEC: 1.6 μg/L ai

14. VERIFICATION OF STATISTICAL RESULTS

| "Parameter" | ts: Result : 'S was to |
|---|---|
| Binomial Test LC ₅₀ (C.I.) | 6.35 (1.6-9.39) μg/L ai |
| Moving Average Angle LC ₅₀ (95% C.I.) | 4.70 (4.04-5.53) μg/L ai |
| Probit LC ₅₀ (95% C.I.) | Probability less than 0.05 Probit should not be used. |
| NOEC | 1.6 μg/L ai |

NOTE: BECAUSE THERE WAS CONTROL MORTALITY, AND NONE OF THE LOWER CONCENTRATIONS PRODUCED ZERO MORTALITY, THE DATA HAS BEEN SUBJECTED TO ABBOTT'S CORRECTION.

Regina Hirsch Zinc Omadine Acute Toxicity to Mysid Shrimp

***************** NUMBER NUMBER PERCENT BINOMIAL CONC. **EXPOSED** PROB. (PERCENT) DEAD DEAD 19 100 1.907348E-04 17 . 19 9.399999 19 19 100 1.907348E-04 5.9 19 36.8421 17.96417 3.2 19 7 36.8421 17.96417 19 1.907348E-04 1.6

THE BINOMIAL TEST SHOWS THAT 1.6 AND 9.399999 CAN BE USED AS STATISTICALLY SOUND CONSERVATIVE 95 PERCENT CONFIDENCE LIMITS, BECAUSE THE ACTUAL CONFIDENCE LEVEL ASSOCIATED WITH THESE LIMITS IS GREATER THAN 95 PERCENT.

AN APPROXIMATE LC50 FOR THIS SET OF DATA IS 6.351465

RESULTS CALCULATED USING THE MOVING AVERAGE METHOD

95 PERCENT CONFIDENCE LIMITS LC50 G SPAN ્ 3ં 5.359227E-02 4.705913 4.042063

5.531044

RESULTS CALCULATED USING THE PROBIT METHOD ITERATIONS

GOODNESS OF FIT PROBABILITY

3.96021 1.198996

7.803023E-03

SINCE THE PROBABILITY IS LESS THAN 0.05, RESULTS CALCULATED USING THE PROBIT METHOD PROBABLY SHOULD NOT BE USED.

SLOPE 4.443864

95 PERCENT CONFIDENCE LIMITS =-.4221077 AND 9.309834

LC50 = 4.856263

95 PERCENT CONFIDENCE LIMITS = 0 AND +INFINITY

2.514866 LC10 =

95 PERCENT CONFIDENCE LIMITS = 0 AND

4.610631

NOTE: BECAUSE THERE WAS CONTROL MORTALITY, AND NONE OF THE LOWER CONCENTRATIONS PRODUCED ZERO MORTALITY, THE DATA HAS BEEN SUBJECTED TO ABBOTT'S CORRECTION.

Regina Hirsch Zinc Omadine Acute Toxicity to Mysids

| **** | ***** | ****** | ****** | ***** | * * * * * * |
|-------|---------|--------|---------|-----------------|-------------|
| CONC. | NUMBER | NUMBER | PERCENT | BINOMIAL | 2 |
| | EXPOSED | DEAD | DEAD | PROB. (PERCENT) | 9) |
| 17 | 19 | 19 | 100 | 1.907348E-04 | |
| 9.399 | 999 | 19 | 19 | 100 | |

Table B.1. Results of analyses of test media containing Zinc Omadine*.

| Nominal Concentration of | Méasured | Percent of | | |
|-----------------------------|------------------|-----------------|------|---------|
| Test Substance (µg/L) | 0 hour | 96 hour | Mean | Nominal |
| Test Media | | · | | |
| 0.0 (control) | ND | ND | ND | |
| 2.4 | 1.3 | 1.8 | 1.6 | 67 |
| 4.0 | 2.0 | 4.4 | 3.2 | 80 |
| 6.4 | 5.6 | 6.1 | 5.9 | 92 |
| 9.6 | 7.7 | 11 | 9.4 | 98 |
| 16 | 15 | 18 | 17 | 106 |
| Laboratory Standard | | | | |
| 10 | 9.2 9.8 10 | 9.8 10 10 | 9.8 | 98 |
| Matrix Spike | | e s | | - |
| 6.4 | 2.9 5.4 | 8.0 8.3 | 6.2 | 97 |
| Laboratory Control S | pike | | | |
| 6.4 | 7.1 | 6.8 | 7.0 | 109 |
| Blank | • | • | | |
| 0.0 | ЙD | ND | ND | |

Notes: 1. ND = none detected (detection limit = 0.80 μ g/L).