US ERA ARCHIVE DOCUMENT

Presented at

Great Rivers Reference Condition Workshop January 10-11, Cincinnati, OH


Sponsored by The U.S. Environmental Protection Agency and The Council of State Governments





Cooperative Agreements With U.S. EPA

- Cooperative agreements between MBI & CABB and U.S. EPA – initiated Oct. 2000 and Aug. 2001.
- Promote and demonstrate the role of biological assessment and criteria in WQ management.
- Examine relationships between biological criteria and biotic and abiotic stressors.
- Regional biocriteria development in streams and large rivers.



30 Years of Progress Through Partnerships:

Biological Indicators

Susan Jackson, US EPA Biological Criteria Program

What Is *Adequate* Monitoring & Assessment (M&A)?

- Biological, chemical, & physical indicators.
- Adherence to stressor, exposure, response roles avoid use of sur ogates.
- Data Quality Objective / adequate for the intended purpose (projuld be defined by WQS).
- Design (scale, scale) intensity) meets multiple management issues and needs.
- The product of M&A is the assessment, not just the data (avoid data rich, information poor syndron(e))
- Professionalism expertise in key disciplines




Three Principal Objectives of Systematic Bioassessment

- Determine if use designations are appropriate and attainable
- Determine condition and status of the resource (including causal associations)
- Are changes taking place over time?


Issues of Large River Bioassessment

- Methods Issues comparability, accuracy
- Bioassessment calibration, validation
- Status and trends sites, reaches, segments
- Scale issues how much of a large river needs to be assessed?
- Local vs. reach scale issues.
- Support of multiple water quality & resource management objectives will require consideration of multiple sampling designs.





Fish Assemblage Assessments of Large and Great Rivers in the Upper Ohio Basin



Midwest Large River Programs:

- ORSANCO night electrofishing, IBI developed; macroinvertebrate method in development; in process of adopting in standards.
- Wisconsin daytime electrofishing, IBI developed; exploring macroinvertebrate methods; not in WQS.
- Ohio EPA daytime electrofishing, IBI developed; macroinvertebrate method and index established; adopted in WQS.
- Other Region V States most have developmental projects underway; some conduct assessments.



ELECTROFISHING METHODS

Wiscon One mile 3000 W, motor in The concern is about the comparability and accuracy of the resulting assessment of environmental quality that are produced by the States and others – methods and the execution of the sampling is the genesis of some largely unrealized problems.

Ohio

500m of shoreline; daytime sampling; 5000 W, 120 Hz; 1 netter (1/4" mesh); motor in downstream direction

ORSANCO (Ohio R.)

500m of shoreline; nighttime sampling; 5000 W, 120 Hz; 1 netter (1/4" mesh); motor in downstream direction

Benthic Macroinvertebrates

Active Sampling Methods Examples





Dome Sampler

Net-based methods (including kicks, dips, jabs, sweeps, & picks)




Grab samplers

Benthic Macroinvertebrates Passive Sampling Methods Examples


- Quantitative
 - Ohio-EPA artificial substrates
 - Maine DEP rock baskets
 - Each state has sampled large rivers for >25 years






The use of regionally relevant datasets to support biocriteria derivation and calibration

Slide Used Courtesy of John Lyons, Wisconsin DNR





Kennebec River (2002-5)

- Wyman Dam to Merrymeeting Bay (30 sites, 2 test areas)
- Follow-up Waterville to Augusta (2002-5)
- Atl. salmon nursery habitat survey (2003)

Androscoggin River (2003)

Errol, NH to Merrymeeting Bay (51 sites)

Sebasticook River (2003)

Douglas Pond to Winslow (9 sites)

Penobscot River (2004)

■ N. Br. To Hamden (40 sites); included W.

tributaries

gash (5 sites),

Croix (12 sites)

Cooperators

- U.S. EPA, Region I
- U.S. EPA, HECD
- Maine DEP
- Maine DIFW
- Maine DMR
- Maine ASC
- U.S. F&WS
- Penobscot Indian Nation
- Trout Unlimited

- St. Croix IWC
- Maine DOC
- NFWF
- GOMCME
- SRWA

Table 1. Key characteristics of a boat electrofishing protocol applicable to Maine and New England large river habitats.

Category/Attribute	Riverine Wadeable ^a (Low-Mod. Cond. ^b	Riverine High Gradient) (Low Cond.)	Riverine Mod. Gradient (Low Cond.)	Riverine Low Gradient (Mod. Cond.)	Impounded (Mod. Cond.)	Impounded (Mod. Cond.)	Tidal (High Cond.)
Drainage Area	<500 mi ²	<500 mi ²	>500-1000 mi ²	>1000 mi ²	NA	NA	NA
2. Platform	Georator ^c (bank set/towboat	14' raft ^d or) 12' johnboat	16' johnboat or 16' raft ^e	16' johnboat	16' johnboat	16' johnboat	16' johnboat
3. Crew Size	3 persons (2 netters)	2 persons (1 netter)	3 persons (2 netters)	3 persons (2 netters)	3 persons (2 netters)	3 persons (2 netters)	3 persons (2 netters)
4. Electrofishing Unit	GPP 2.5, 5.0 ^e or equivalent	GPP 2.5, 5.0 or equivalent	GPP 5.0 or equivalent	GPP 5.0 or equivalent	GPP 5.0 or equivalent	GPP 5.0 or equivalent	GPP 5.0 or
5. Power Source	2500-5000 Watt Alternator	5000 Watt Alternator	5000 Watt Alternator	5000 Watt Alternator	5000 Watt Alternator	5000 Watt Alternator	5000 Watt Alternator
6. Unit Settings ^f	High 120 Hz	High 120 Hz	High 120 Hz	Low or High 120 Hz	High 120 Hz	Low or High 120 Hz	Low 120 Hz
(% of Low or High Rang	je) NA	2-4 Amperes (100%)	2-4 Amperes (100%)	4-8 Amperes (60-100%)	2-4 Amperes (100%)	4-8 Amperes (60-100%)	>8-15 Amperes (50-80%)
7. Anodes ^g	Net Ring	2 gangs	3 gangs	3 gangs	3 gangs	3 gangs	2 gangs
8. Cathodes	rat tail	6'	8'	8'	8'	8'	8'
Sampling Direction Distance	& Upstream 0.2-0.5 Km	Downstream 0.5-1.0 Km	Downstream 1.0 Km	Downstream 1.0 Km	Downstream 1.0 Km	Downstream 1.0 Km	Downstream 1.0Km
10. CPUE ^h Basis	Per 0.5 Km	Per Km	Per Km	Per Km	Per Km	Per Km	Per Km
11. Time Sampled ^I	Not tested	3500-4500 s	4000-5500 s	3500-4500 s	3000-4000 s	3000-4000 s	3500-4500 s
12. Time of Day	Day	Day	Day	Day	Day or Night	Day or Night	Day

Suddeable defined as sites where a raft or boat mounted apparatus cannot be used due to shallowness of depth – accessibility is not a criterion.

Typical relative conductivity ranges: Low (15-40 μs/m²); Moderate (40 – 200 μs/m²); High (>200 μs/m²).

Employs a primary net ring as the anode that is operated by the primary netter backed by an assist netter - the unit is either bank set or towed on a small skiff (towboat).

d This platform was extensively tested in 2005.


This platform has not been tested in Maine, but it has worked well elsewhere and in similar conditions.

This does not constitute an endorsement of a particular brand or product name and is for methodological identification only.


Unit settings are selected to produce the highest voltage and amperage output; these are what typically worked in each conductivity range and habitat type.


Anodes consist of gangs or multiple strands of wire as described under Equipment Specifications.


MAINE RIVERS TIME ELECTROFISHED (2002-3)



MAINE RIVERS ELECTROFISHING (2002-3)

















Tiered Aquatic Life Uses: A Tool for Ecosystem Management

Hydrologic Alteration and Ecological Communities in the East
Amherst, MA, UMASS and TNC
October 20, 2005

Susan Davies, State of Maine, and Susan Jackson, U.S. EPA



Use of Biological Information to Tier Designated Aquatic Life Uses in State and Tribal Water Quality Standards



Ecotype

[Specific

Tiered Aquatic Life Use Conceptual Model: Draft Biological Tiers

- Natural structural, functional, and taxonomic integrity is preserved.
 - Structure and function similar to natural community with some additional taxa & biomass; no or incidental anomalies; sensitive non-native taxa may be present; ecosystem level functions are fully maintained

The Biological Condition Gradient:
A conceptual model for interpreting detrimental change in aquatic ecosystems

Susan P. Davies and Susan K. Jackson (Ecological Applications [in press])

conspicuously unbalanced distribution of major groups from that expected; organism

complexity and redundancy; increased build up or export of unused materials.

Extreme changes in structure; wholesale changes in taxonomic composition; extreme alterations from normal densities; organism condition is often poor;

anomalies may be frequent; ecosystem functions are extremely altered.

LOW — Human Disturbance Gradient — HIGH

Biological Criteria: I

• Narrative ratings or numerical values which are based on the numbers and kinds of aquatic organisms (i.e., assemblage) which are found to inhabit a particular stream or river sampling location.

Biological Criteria: II

• Biological criteria are indexed to the reference assemblage of aquatic organisms within a particular geographical region (i.e., ecoregion) and with respect to stream and river size.

Establishing Reference Condition

I. Reference Sites

- Minimally to least impacted sites.
- Cultural setting & abiotic criteria qualitative process used in 1980s.
- Subsets of sites needed for different ecotypes, water body types, and regions.
- Part of routine monitoring <u>resampling over a 10</u>
 <u>yr. time interval</u>*).
- * a complete set of re-sampled reference data (1990-1999) is now available for Ohio.


Establishing Reference Condition

II. Reference Condition


- Data collected at reference sites.
- A distribution of data, not a single fixed data point.
- Should include upper tiers of Biological Condition Gradient.
- Alternative approaches can be used when empirical data is lacking (historical archives, expert panels).
- Used first to *calibrate* metrics, then to *set biocriteria*.

Assessing Biological Integrity in Running Waters A Method and Its Rationale

James R. Karr Kurt D. Fausch Paul L. Angermeier Philip R. Yant Isaac J. Schlosser




Illinois Natural History Survey Special Publication 5 September 1986







Guidelines for Deriving Regionally Relevant "IBI Type" Assessment Tools

- Karr et al. (1986) provides guidance for metric development, substitution, and modification.
- Requires detailed knowledge of the regional fauna including life history, taxonomy, zoogeography, and natural history.
- Requires an extensive database from consistent sampling of both reference condition and a gradient of human disturbance.
- Requires extensive testing of candidate metrics and aggregate indices.










Calibration of Metrics Using Regional Reference Sites

- Scatter plot of metric value by appropriate calibration vector (e.g., watershed area).
- Determine 95% maximum line of best fit across surface of scatterplot; driven by best reference sites.
- Area beneath 95% line is subdivided (e.g., trisection) to determine metric scores - most data points should occur in upper ranges.
- This method reduces the influence of slightly degraded sites that may not biologically reflect the intent of reference condition.
- Slope of 95% line conservatively assumed to be zero for boat sites.


Ohio IBI Calibration & Biocriteria Derivation Process




I. Select & sample reference sites




II. Calibration of IBI metrics






IV. Establish ecoregional patterns/expectations




V. Derive numeric biocriteria: Codify in WQS


III. Calibrated IBI modified for Ohio waters



VI. Numeric biocriteria are used in bioassessments

Ohio Biological Criteria: Adopted May 1990 (OAC 3745-1-07; Table 7-14)







Biological Criteria: III

• Biological criteria represent a calibrated assessment tool which fosters an organized goal setting process in an effort to reconcile human impacts and guide restoration efforts.


Maine DEP Bioassessments




ESTIMATED TSS (KG/DAY) FOR THREE PULP AND PAPER MILLS ON THE PENOBSCOT RIVER




GENERIC RICHNESS




RELATIVE ABUNDANCE OLIGOCHAETA



Hillside Road (RM 15.6) Fish and Macroinvertebrate Trends





Ohio Large Rivers Bioassessment: 1979 - present

- Multiple stressors (point & nonpoint sources, habitat, hydromodification)
- Intensive survey design
- Repeat samplings >1 to 5-10 years; supports before & after assessments
- Aggregate assessment for waterbody subclass (>150-500 mi.²)




Domestic Wastewater


Industrial Wastewater

Many large rivers are effluent dominated by treated sewage flows – growth pressures are taxing existing infrastructure and assimilative capacity

Multiple, Interactive Sources

Acute/Chronic Effects





Changes in Fish Assemblage Status in Ohio's Nonwadeable Rivers and Streams over Two Decades


CHRIS O. YODER¹ AND EDWARD T. RANKIN

Midwest Biodiversity Institute and Center for Applied Bioassessment and Biocriteria Post Office Box 21561, Columbus, Ohio 43221–0561, USA

MARC A. SMITH, BRIAN C. ALSDORF, DAVID J. ALTFATER, CHARLES E. BOUCHER, ROBERT J. MILTNER, DENNIS E. MISHNE, RANDALL E. SANDERS, AND ROGER F. THOMA

Ohio Environmental Protection Agency, 4675 Homer Ohio Lane, Groveport, Ohio 43125, USA

Abstract.—A systematic, standardized approach to monitor fish assemblages has been applied in Ohio's rivers since 1979. A primary objective is the assessment of changes in response to water pollution abatement and other water quality management programs. All major, nonwadeable rivers were intensively sampled using standardized electrofishing methods and a summer—early fall index period. Most rivers were sampled two or three times, before and after implementation of pollution controls at major point source discharges and best management practices for nonpoint sources. A modified and calibrated index of biotic integrity (IBI) was used to demonstrate and evaluate changes at multiple







Figure 4.. The 1996 middle Scioto River study area showing principal streams and tributaries, population centers, major pollution sources and environmental monitoring stations.

Application of Biocriteria in Complex Settings


1. Free-flowing river (WWH use designation): Upstream from urban area ECBP Ecoregion - Wading site type:



Within urban area ECBP Ecoregion - Boat site type:

$$IBI = 30$$

 $MIwb = 6.6$
 $ICI = N/A$



3. Free-flowing river (WWH use designation):

Downstream from urban area

ECBP Ecoregion - Boat site type:



Limiting Factors:

- chemical water quality
- physical habitat
- flow/energy dynamics

Limiting Factors:


- physical habitat
- energy/flow dynamics
- chemical water quality

Limiting Factors:

- chemical water quality
- energy/flow dynamics
- physical habitat

Flow Direction


Resurrecting the Concept of the Pollution Impact Continuum in Rivers: It Still Exists




RIVER MILE


After Bartsch and Ingram (1967)

Demonstrating Changes Through Time: Scioto River 1980 - 1994



Demonstrating Changes Through Time: Scioto River (1979 – 1996)





Measuring and Managing Environmental Progress: Hierarchy of Indicators

- 1. Management actions
- 2. Response to management
- 3. Stressor abatement
- 4. Ambient conditions
- 5. Direct exposure to effects of pollution
- 6. Biological response

Administrative indicators

[permits, plans, grants, enforcement, [technologies used, BMPs installed]

Stressor indicators

[effluent reduction, changes in land-use practices]


Exposure indicators


[pollutant conc., flow or physical habitat alteration, assimilation and uptake of pollutants, reduced spawning habitat, nutrient dynamics changes, sedimentation effects, etc.]

Response indicators


[biological metrics, multimetric indexes, target species, other biological measures]

Endpoint of Concern: "ecological health"





Linking Biological Responses to Stressors



Good quality biological data and a process for using it is essential for improving the management of aquatic resources and bringing policy and legislation into the 21st Century