


US EPA ARCHIVE DOCUMENT

Real -Time Monitoring to Assess Mercury Emissions from Storage Activities




Joseph Graney
Associate Professor
Department of Geological Sciences and Environmental Studies
Binghamton University

Assessment Goals:

- 1) Monitor Changes in Vapor Phase Mercury Concentrations Following Changes in Storage Practices :
 - Before, During and After Transport
 - Before, During and After Over-packing
 - Residual Concentrations Prior to Base Closures
- 2) Design monitoring methods that could be implemented by others





DoD Federal Mercury Stockpile Inventory Status

<u>Location</u>	<u>Amount</u>	<u>Status</u>
Binghamton, NY	(-211 mt)	Shipped to Somerville Fall 2000
Oak Ridge, TN	(-699 mt)	Shipped to Warren Fall 2004
Somerville, NJ	2617 mt	Over-packed Nov.2001 - Feb.2002
Warren, OH	1262 mt	Over-packed March 2002
New Haven, IN	557 mt	Over-packed April 2002

mt- metric tons

Warehouse Storage Complex
Binghamton Depot
Defense National Stockpile
Defense Logistics Agency



Pallets Containing Mercury Flasks



Storage Prior
to Over-packing

Individual Flask
of Mercury
with Threaded Seal



Mock-Up of the Over-packing Procedure



size of an individual flask



completion of over-packing

New Haven Depot
Storage (post over-
packing procedure)



Warren Depot
Storage (post over-
packing procedure)



Fundamental Mercury Monitoring Concepts

- There are natural and anthropogenic sources of mercury vapor
- There is a global mercury vapor background regardless of where you reside (a low, but measureable baseline concentration)
- Everyone is exposed to mercury vapor on a daily basis
- Concentrations in urban areas tend to be higher than in rural locations
- You are likely exposed to higher concentrations of mercury vapor in indoor versus outdoor activities
- There are different types of mercury species with differing toxicities
 - Elemental Hg^0 (least toxic)
 - Oxidized Hg^{+2}
 - Methylated CH_3Hg (most toxic)
- Elemental Hg^0 vapor is the “easiest” to measure, and is likely to be the most common form (by far) in the air inside the DoD warehouses

Examples of Mercury Vapor Exposure Guidelines

- Inside Warehouses (worker exposure)
- 25,000 ng/m³ (one hour exposure, ACGIH)



- Offsite (residential exposure)
- 300 ng/m³ (average annual exposure, New York State recommendations)



Warehouse Construction, Access, and Ventilation Systems may all exert Control on Mercury Vapor Emissions



Overhead Doors and Wall Vents




Roof Vents



Monitoring Methods

- Tekran and Lumex Instruments
- Inside Warehouses
 - conduct x-y grid sampling
 - conduct x-y-z gradient sampling
- Outside Warehouses
 - emissions from vents (on warehouse roofs)
 - ambient air in adjacent residential areas
- Document Temporal and Spatial Variations
- Inclusion of Meteorological Conditions Assessment

Real-Time Mercury Vapor Monitoring



Tekran 2537A

5 minute sample collection
Hg conc. range 1.0 - 2000 ng/m³
cart mounted - AC power



Ohio-Lumex

1 second sampling interval
Hg conc. range 20 - 50,000 ng/m³
portable - battery powered

Results from Mercury Vapor Monitoring with Tekran Instrumentation Prior to Over-Packing




Oct. 26th, 2000. Monitoring vapor phase mercury concentrations over wooden box pallets containing flasks of mercury in Warehouse 11D.

Binghamton Depot Fall 2000


Hg Concentrations Inside the Warehouse are Related to Temperature Inside and Outside Warehouse (however natural ventilation rates also exert controls on the concentrations)

Binghamton Depot Inside Warehouse 11

Oct.13-16, 2000





Temperature Variations Inside and Outside Warehouse 11 Oct.13-16, 2000



Somerville Depot May 2001


Monitoring emissions from roof vents Prior to Over-packing



Warehouse Roof Schematic
(above 4 warehouse sections)


Small Elevations in Levels of Mercury Vapor
were found outside of the Warehouses
(superimposed over baseline concentrations)

Somerville Depot May 8-10, 2001
Inlet on Top Of Warehouse 3E3




Findings: 1) Inside-Outside temperature difference provides conditions conducive to emission of Hg vapor through roof vents at Somerville, 2) Meteorological variability is also reflected in changes in the concentration levels at the Inlet location


Somerville Depot May 8 - 10, 2001
Warehouse 3E3



Somerville May 8-10, 2001
Meteorology



Prior to the removal of the Mercury Stockpile, what was the source of the vapor phase mercury in the residential neighborhood adjacent to the Binghamton Depot?



Measurement
Location

N-360


W-270

E-90

S-180

There should be
supporting evidence from
meteorological measurements...

Outside Private Residence on Cornish Avenue
Oct. 9 -12, 2000




Note: The Hg concentrations are very low!

Times of “Elevated” Mercury....

Time A: Evening, Low wind speeds, pollution buildup enhanced by river valley topography (Hg source possibly from the Depot, but not conclusive)

Time B: Daytime, Winds from the southwest (distal Hg source, not from the Depot...)

Outside Private Residence on Cornish Avenue
Oct. 9 -12, 2000



Use of the Lumex Instrumentation Before, During, and After Over-packing Operations



Hg Concentrations Before and During Over-packing Inside a Warehouse at the Warren Depot (x-y grid sampling)

Warren Depot February 2002
Hg Conc. (ng/m³) Prior to Over-packing
Using Lumex inside Warehouse

<10	20	
<10	30	
	Containment	Cage Area
	68	60
	63	90
65	67	65

Warren Depot March 2002
Hg Conc. (ng/m³) During Over-packing
Using Lumex inside Warehouse

2034	2617	
2175	3013	
	Containment	Cage Area
	11900	6744
	13460	15770
2324	8230	12520

- Mercury originally stored inside the “cage” area
- Overpacking took place within containment area
- Workers required to wear respirators if Hg Concentrations are > 25,000 ng/m³


Results after Over-packing Activities Had Been Completed at Warren

Warren Depot Warehouse Sampling Location Template

	1					
	2	Drum Stockpile				
	3					
	4	Center				
	5					
	6					
	7	Over- packing Area	Old Cage Area			
	8					
S1		S2	S3	S4		




Grid Sampling Results at Warren...



Concentrations are similar throughout the warehouse (well mixed)


Monitoring Rate of Hg Concentration Decrease after Opening Overhead Doors at Warren Depot

Warren Depot Venting Warehouse 6/25/02
Location: Center of Warehouse using Lumex




Mercury concentrations decrease due to mixing with lower concentrations within the air outside the warehouse (increasing the air exchange rate)

Locating Sources of Residual Hg Vapor Following Warehouse Venting (x-y grid sampling)



Vertical Gradient Sampling Cross-Section (x-y-z) to further define the residual Hg sources

Warren Depot Warehouse Sampling Location Template



Results from Vertical Gradient Sampling at Warren...

Vertical Gradient Sampling in Warehouse 2A, Warren Depot, June 24, 2002

All mercury concentrations in ng/m³

Doors Closed

Sampling at 11:20 A.M.

Inside T = 77 F, Outside T = 91 F

Location	In Stockpile	Center	Near Cage
16 feet	2732	4250	4520
12 feet	3443	4126	4140
8 feet	3686	4035	4138
4 feet	3287	3810	4370
Floor	3330	4450	9763

Doors Opened at 12:12P.M.


Sampling at 1:50 P.M.

Inside T = 84 F, Outside T = 94 F


Location	In Stockpile	Center	Near Cage
16 feet	81	167	180
12 feet	89	153	225
8 feet	103	96	175
4 feet	111	169	173
Floor	177	536	4285

Highest mercury vapor concentrations were at floor level in area where flasks were stored prior to over-packing procedure

Hg Concentrations increased to previous morning's levels following the venting experiments, how do we decrease these residual concentrations?




Warren June 25th Morning (pre-vent)
Breathing Level Measurements T= 79F




Floors had been cleaned
three times prior
to return site visit in
September....

Floor Cleaning Methods were
used to Reduce Residual
Hg Concentrations
at Warren....

Warren 9/04/02 Morning T=77F
Breathing Level Measurements



New Haven Depot June 26, 2002




Before

Wall vents had been left in open position for two months prior to return visit

Residual Hg Concentrations at New Haven were reduced through use of natural processes....

New Haven August 23, 2002
(after increasing natural ventilation)



After

Conclusions

- Highest Hg concentrations were associated with over-packing operations
- Over-packing during cool weather conditions helped to limit worker exposure to Hg vapor
- Highest residual Hg concentrations were located at floor level associated with containment areas and forklift traffic
- Hg movement and concentrations within warehouses reflected changes in meteorological conditions

Conclusions continued...

- Residual Hg concentrations were lowered through increasing natural ventilation rates as well as floor cleaning activities
- Over-packing operations were successful in confining the sources of mercury emissions and lowering Hg concentrations
- Over-packed Hg inventory is stored in a secure environment from health and safety perspectives
- Tekran instrumentation is ideal for monitoring low level mercury concentrations outside of warehouses, Lumex instrumentation is ideal for real - time measurements inside warehouses

Acknowledgements

- Binghamton University
 - Tim Eriksen (mercury vapor sampling)
 - Lisa Snopkowski (Depot images/GIS support)
- Binghamton, New Haven, Somerville and Warren Depot Defense National Stockpile Personnel
- Defense Logistics Agency
- U.S. Army Corp of Engineers
- Parsons Engineering
- New Jersey Institute of Technology
- Much of the technical information from this presentation has been published in the Proceedings from the 2002 Symposium on Air Quality Measurements and Technology (sponsored by the Air and Waste Management Association)

